

TOMOGRAPHIC AND HYPERSPECTRAL ANALYSIS OF POROUS THREE-DIMENSIONAL SOLID OXIDE FUEL CELL CATHODES AT MULTIPLE LENGTH SCALES

Joshua Taillon, Christopher Pellegrinelli, Yilin Huang, Eric Wachsman, and Lourdes Salamanca-Riba
University of Maryland, College Park

* Supported by DOE-SECA under contract no. DEFE0009084
and NSF GRFP grant no. DGE 1322106.

2015 Fall MRS – AAA1.02
Monday, November 30, 2015 – 9:00 AM
Hampton Room, Sheraton Hotel

THE DEPARTMENT *of*
MATERIALS SCIENCE AND ENGINEERING




Introduction to Solid oxide fuel cells

- Solid oxide fuel cells
 - Low cost, flexible

- Problems?
 - High operating temperatures
 - Cathode poisoning
 - H₂O, CO₂, SO₂
 - Adverse effects

- What is primary cause of degradation?
 - **Microstructure!**
 - Previous work:

- Quantification in the FIB/SEM:
 - J. Wilson, S. Barnett, *Electrochem. Commun.*, **11**(5), 1052 (2009).
 - D. Gostovic, E. Wachsman, *et al.*, *J. Am. Ceram. Soc.*, **94**(2), 620 (2011).



Our task:

Use the FIB/SEM (and TEM) to characterize microstructural changes as cathode degradation occurs, and relate these changes to those in cell performance.



Our goal:

Better understanding of the fundamental mechanisms behind cathode degradation.

Outline

- Data acquisition
 - Sample prep and imaging conditions
- FIB/SEM Data processing and quantification
 - Filters, artefact correction, and segmentation
 - Microstructural quantification
- STEM-EELS Hyperspectral imaging
 - Machine learning signal decomposition

Experimental - Button cell testing



Cross-section view

- Symmetric cathode cells
 - 8-YSZ electrolyte
 - 50 wt. % LSM/YSZ cathode paste
- Sintered at 1000°C for 1hr
- Aged for 250hr at 800°C
 - Polarization was constant 60mA/cm²
- Four conditions compared:
 - Aged – dry air
 - Aged – dry air – cathodic polarization
 - Aged – 3% H₂O – anodic polarization
 - Aged – 3% H₂O – cathodic polarization


FIB/SEM DATA ACQUISITION

FIB/SEM Data acquisition

- Our results (and conclusions) can only be so good as our inputs
 - We need good inputs! (GIGO)
- Important considerations:
 - Initial sample preparation (pre-FIB)
 - Sample preparation within the FIB/SEM
 - Slicing resolution (for fidelity of reconstruction)
 - Electron beam parameters - image noise and resolution vs. data acquisition time
 - What is it we need to accentuate?

Pre-FIB sample prep

1. Vacuum impregnation of porous structure
2. Grinding/polishing to 1200 grit
3. Carbon coating and sample mounting



Instrumentation

- FEI Helios 650
 - Part of the Center for Nanoscale Science and Technology (CNST) user facility at NIST
 - Multichem, iFast Developer Kit, etc.
- Auto Slice and View version 1.2
- Avizo Fire + personal Python code
- Tescan Gaia (+ Xeia) at UMD
 - Process development underway



FEI Helios 650 at NIST (CNST)





Tescan Gaia at UMD AIMLab

FIB/SEM DATA PROCESSING

Experimental – post processing of data



- Post-processing done with mix of software:
 - ImageJ/Python
 - Intensity gradient correction
 - Fiducial tracking/slice thickness measurement
 - Avizo Fire:
 - Non-local means filtering of data¹ (also Perona–Malik diffusion filter)
 - Watershed segmentation algorithm²




¹ Based on A. Buades *et al.* in 2005 *IEEE Comput. Soc. Conf. Comput. Vis. Pattern Recognit.*, Vol. 2, p. 60. IEEE.

² L. Vincent and P. Soille, *IEEE Trans. Pattern Anal. Mach. Intell.*, 13(6), 583 (1991).

Visualizations of LSM/YSZ Fuel Cell reconstruction




Visualizations of LSM/YSZ Fuel Cell reconstruction




Results – Phase percolation

- Comparison of longest section of each phase to overall network
 - Used 5 longest components
- Result:
 - YSZ and pore completely interconnected
 - LSM is limiting transport





Triple phase boundary (L_{TPB}) determination

- Intersection of three phases is necessary for the oxygen reduction reaction to occur:
 - ORR: $\frac{1}{2}O_2 + 2e^- \leftrightarrow O^{2-}$
 - This quantity can be directly related to cell performance
- Within analysis volume, a phase and boundary site can be described as **active**, **inactive**, or **unknown**
- Labels depend on connection to edges
 - Unknown have at least 1 border with edges (dead-end)
 - Active have two borders across a dimension (transverse)
 - Inactive networks have no intersection with an edge (isolated)
- Collaboration with Scientific Applications and Visualization Group at NIST
 - Implemented edge-counting more accurate than morphological expansion (current trend in literature)





Results – Triple phase boundaries



- Total ρ_{TPB} relatively constant (except H₂O-anodic, which has low sampling volume)
- H₂O-cathodic has significant decrease in active TPB density, suggesting drop in active sites for ORR

Results – Triple phase boundaries




- Total ρ_{TPB} relatively constant (except H₂O-anodic, which has low sampling volume)
- H₂O-cathodic has significant decrease in active TPB density, suggesting drop in active sites for ORR

TEM-EELS HYPERSPECTRAL IMAGING

Electron Energy Loss Spectroscopy (EELS)


- E-beam has many interactions with specimen:



Adapted from Williams and Carter, *Transmission Electron Microscopy*, (2009).


Electron Energy Loss Spectroscopy (EELS)

- E-beam has many interactions with specimen:



Adapted from Williams and Carter, *Transmission Electron Microscopy*, (2009).

- EELS is measurement of the energy lost when an electron interacts with the sample:




Williams and Carter, *Transmission Electron Microscopy*, (2009).

Decomposition analysis


- Machine learning for hyperspectral decomposition
 - How to tease out convoluted and complex signals
 - Use redundancy of information in spatial dimensions to learn more about differences in the signal dimension(s)
 - Used in EEG, audio processing, fMRI, etc.

- Non-negative matrix factorization and Blind source separation
 - Finding simpler descriptive basis vectors of overall data; one component per “source”





Adapted from: <https://upload.wikimedia.org/wikipedia/commons/f/f9/NMF.png>

Hyperspectral decomposition of oxygen signal







Hyperspectral decomposition of oxygen signal

- Discrete surface component
 - Independent from LSM or YSZ
- Lack of peak in O-K EELS signal at surface
 - Suggests decrease in oxygen 2nd nearest neighbors
 - More oxygen vacancies
- Increase in edge onset (compared to LSM)
 - Increased bandgap, lower electrical conductivity




D. Muller, et al., *Nature.*, **399**, 758 (1999).



Hyperspectral decomposition – Mn segregation



Mn-segregation valence analysis





Mn-segregation valence analysis



S.J. Shih, et al., *J. Electrochem. Soc.*, **158**(10), B1276, (2011).

Mn-segregation valence analysis



S.J. Shih, et al., *J. Electrochem. Soc.*, **158**(10), B1276, (2011).

- EELS reveals mobile Mn ions with valence of ≈ 2.5 at the interface of YSZ particles
 - Suggests not a full perovskite coordination

Summary

Conclusions

- Developed methods to quantify 3D microstructure of solid oxide fuel cell cathodes
- Subtle changes in LSM/YSZ microstructure occur; which agree with subtle changes in cell performance
- $\rho_{\text{TPB,active}}$ decreases when aged under H₂O contamination and cathodic polarization
- Segregation of Mn and La to YSZ grain boundaries in H₂O-cathodic (but not Sr); change in LSM Mn valence

Ongoing Work

- Analyze and quantify composition of segregation products using TEM/EELS
- Further correlation with EIS data from same samples
- Investigation of LSCF/GDC composite cathode degradation

Acknowledgements



SECA, Contract No. DEFE0009084
NSF GRFP, Grant No. DGE 1322106

NIST



Scientific Applications
& Visualization Group

Joshua
Schumacher

John Hagedorn
Wesley Griffin
Judith Terrill



Danijel Gostovic,
Nicholas Vito



HyperSpy
hyperspectral data analysis



UNIVERSITY OF
MARYLAND



MARYLAND NANOCENTER
AIMLAB
ADVANCED IMAGING & MICROSCOPY LABORATORY



Open source projects:
Scikit-fmm
HyperSpy
OpenCV
ImageJ/Fiji

THANK YOU

Questions and comments?

Email:

jtaillon@umd.edu

and/or

riba@umd.edu